


TR5102 Proximity Speed and Phase Reference Transmitter

TR5102 is a cost-effective solution for monitoring the speed on your balance of plant machines. TR5102 combines the proximity probe driver and the signal conditioning circuit into one package. It will work with proximity probe and extension cable as a system.

Features

- Does not require proximity probe driver
- Buffered output/GAP available for portable vibration analyzer
- Work with other manufactures 5mm, 8mm and 11mm probes
- Aluminum cast case with epoxy potting for hazardous area and reliability
- Same size as a proximity driver



85(3.35")

Plate Mounting

0





Specifications

Electrical

Power Supply:

20-30VDC, 50mA.

Speed Response:

 $0 \sim 50,000$ pulse per minute.

Sensor Interface:

Connection:

Special 95Ω coaxial cable with connector.

Probe:

5mm, 8mm, and 11mm probes that includes: TM0180, TM0105, TM0110, 3300, 7200 series.

Buffered Output:

Raw speed and phase reference signal

Nominal 2~ 18VDC.

Impedance: 100Ω .

Maximum cable distance: 300m (1000ft).

Overall Speed Output:

4-20mA, source.

Driving load resistance up to 750Ω .

Physical

Dimension: Height: 75mm (2.95"), see figuration.

Weight: 1.0kg (2.0 lb).

Environmental

Temperature:

Operation: -35° C ~ $+70^{\circ}$ C. Storage: -40°C ~ +100°C.



PVIVA Proximity Transmitters and Seismic Vibration Transmitters

Humidity:

90% non-condensing.

Ordering Information

Standard configuration:

TR5102-A01-E00-F00-G00

8mm probe:

TM0180-A07-B00-C05-D10

Extension cable:

TM0181-A40-B00

TR5102-AXX-EXX-FXX-GXX

AXX: Full Scale.

A00: 0 ~ 1,000 rpm

A01*: 0 ~ 3,600 rpm

A02: 0 ~ 6,000 rpm

A03: 0 ~ 10,000 rpm

A04: 0 ~ 30,000 rpm

A05: 0 ~ 50,000 rpm

EXX: Probe and Cable.

E00*: TM0180, 5m Cable

E01: TM0180, 9m Cable

E02: 8mm Probe, 3300, 5m Cable

E03: 8mm Probe, 3300, 9m Cable

E04: 8mm Probe, 7200, 5m Cable E05: 8mm Probe. 7200. 9m Cable

E06: TM0105. 5m Cable

E07: TM0105, 9m Cable

E08: TM0110, 5m Cable

E09: TM0110. 9m Cable

E10: 11mm Probe, 3300, 5m Cable

E11: 11mm Probe, 3300, 9m Cable

E12: 11mm Probe, 7200, 5m Cable

E13: 11mm Probe, 7200, 9m Cable

E16: 3000, 190 Probe, 15 Feet Cable

E17: 3000, 190 Probe, 20 Feet Cable

E18: 3000, 300 Probe, 15 Feet Cable

E19: 3000, 300 Probe, 20 Feet Cable

E20: 7200, 5mm Probe, 5m Cable

E21: 7200, 5mm Probe, 9m Cable

FXX: Teeth per Revolution.

F00*: 1

F02: Customer specify, number of teeth =XX

GXX: Mounting.

G00*: DIN rail mounting.

G01: Plate mounting.

* Denote factory default.

TR5102 Accessories

TR5102 must works with proximity probe transducer.

TM0180: 8mm probe.

TM0105: 5mm probe.

TM0181: Extension cable.

Field-wiring Diagram

